LITETRONICS®

3 Pin Photocontrol for Area Light and Flood Light 120-277V (OLAPC1)

Installation Instructions



SAFETY INSTRUCTIONS AND WARNINGS

- When using electrical equipment, basic safety precautions should always be observed
- This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved
- Installation should only be conducted by a qualified electrician in accordance with NEC and any relevant local building codes.
- Be certain electrical power is OFF before and during installation and maintenance.
- To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or sharp objects.

WHAT COMES IN THE BOX

INSTRUCTIONS


Before Installation, carefully remove all parts from the packaging. Inspect product for defects due to shipping.

Always turn off the power supply from main circuit breaker first!

Figure 1

PHOTOCONTROL INSTALLATION

- 1. Turn off power.
- Photocontrol should be installed on the back of light. Replace shoriting cap with photocontrol. (Figure 1)
- 3. Make sure the installation is complete and secure before turning on the power.



Photocell
Flood Light
Socket
Lamp

Thank you for choosing

LITETRONICS®

6969 W. 73rd Street Bedford Park, IL 60638

WWW LITETRONICS COM

CustomerService@Litetronics.com or 1-800-860-3392





The information and product specifications contained in these instructions are based upon data believed to be accurate at the time of printing. This information is subject to change without notice and without incurring liability. If you have questions regarding specific product details, please contact us at 800-860-3392 or via email at customerservice@litetronics.com. To check for an updated version of these instructions, please visit www.litetronics.com.

3 Pin Photocontrol Installation Instructions