



## **IMPORTANT:**

- Read all instructions carefully before attempting installation. If you do not understand these instructions. please consult your local distributor.
- Thoroughly inspect the fixture for any freight damage; freight damage should be reported to the delivery carrier.



**WARNING:** Disconnect power during installation and before servicing.



### **SAFETY:**

- This fixture must be wired in accordance with the National Electric Code and applicable local codes or ordinances.
- All work should be performed by a qualified electrician.
- To insure personal safety, proper grounding is required (connect green fixture lead to supply around).

# **MWP Series M**edium Wall **P**ack **LED**



#### MOUNTING:

- 1. Open the fixture from the front by removing the two screws located on the right side of the housing.
- 2. Unplug door and led assembly wiring harness from backplate.
- 3. Lift lens door and led assembly off hinges and aside for later reinstallation.
- 4. Knock out / drill holes in the rear housing for mounting fixture to wall and for securement to junction box (j-box not provided).
- 5. Apply silicon sealant (not provided) to any holes to prevent water entry.
- 6. Secure fixture to wall with two or more screws (not provided).
- 7. Secure fixture to junction box with screws.

### WIRING CONNECTIONS:

- 8. Connect the black fixture wire to the black supply wire (line).
- 9. Connect the white fixture wire to the white supply wire (neutral).
- 10. Connect the green fixture wire to the junction box ground wire.

#### **REASSEMBLY / LAMP INSTALLATION:**

- 11. Reinstall door and led assembly.
- 12. Plug wiring harness back together.
- 13. Close door replace the two screws located on the right side of the housing lens door.

### TROUBLESHOOTING TIPS: If the fixture fails to operate properly, check the following:



- √ Verify fixture wiring (refer to schematic printed on ballast label).
- ✓ Verify proper line voltage is present and wired to ✓ Verify that the fixture is grounded. the correct ballast input voltage lead.



**WARNING:** This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.